To Redial a Number

- Lift the handset, press Redial soft key.
- If you are using speakerphone, press Redial soft key.

To Hold a Call

Press Hold button.

To Retrieve Held Call

- Press the **Resume** soft key or the flashing green line button.
- If your phone supports multiple lines, you can use line buttons to swap between holding and active calls.

To Transfer a Call

- 1. Press the **Transfer** button.
- 2. Dial "transfer to" number.
- 3. Press the Transfer button again or the soft key that has transfer on the screen.
- 4. Hang Up

Cancel Transfer

• Press Cancel soft key

To Place a Conference Call

- During a call, press Conference button to open a new line and put first party on hold.
- 2. Place a call to another number.
- When call connects, press Conference again to add new party to existing call with first party.

To View Call History

- 1. Press the **Applications** button.
- Select Call History. (Use the Navigation bar and button to scroll and select.)
- 3. Select **All Lines** or the line that you want to view.
- Press the Exit soft key to return to the Call History screen.

Listening to Messages

When you have a new message the light on your phone handset will be illuminated an a message waiting icon will be displayed on the screen).

To listen to new messages:

- 1. Press the Messages button
- 2. Enter your password.
- You will then heard how many messages you have and be prompted to press 1 to hear new messages.

Change Screen Contrast

- 1. Press the **Applications** button
- Select Preferences. (Use the Navigation bar and button to scroll and select.)
- 3. Select Contrast.
- 4. To increase contrast, press the up arrow on the Navigation bar. To decrease contrast, press the down arrow.
- Press the Save softkey to set the contrast level, or press the Cancel softkey to exit.

For Assistance

For technical assistance with Telephones please contact the <u>IT Service Desk</u>:

Location: A700

Phone: (713) 221-8031 (x3000)

Email: ithelp@uhd.edu

For training opportunities for Telephones please contact the <u>IT Training Group</u>:

Location: A700

Phone: (713) 221-8200 (x8200) Email: tllctraining@uhd.edu



Cisco Unified Communication System

Telephone Model 6941



Telecommunications

University of Houston

DOWNTOWN



To Use the Quick Reference Card

- Complete numbered items in sequence.
- Choose only one bulleted item.
- Bold terms identifies soft keys.

To Place a Call

- Lift handset and dial number.
- Dial number and then lift the handset.
- Press line button for your extension, dial the number, and then lift the handset.
- Press New Call soft key, dial number, and then lift handset.
- If you have selected a number from a directory, press the Line / Headset / Speaker button.

To Answer a Call

- Lift the handset.
- If you are using a headset, press the **Headset**button
- If you are using the speakerphone, press the **Speaker** button ①.

To End a Call

- Hang up the handset.
- If you are using a headset, press EndCall softkey.
- If you need to end a speakerphone call, press button or EndCall softkey.

To Call From Contacts

- 1. Press the button Contacts button.
- 2. Press 2 to highlight Corporate Directory and then
- Use the Navigation bar to select any of these criteria to search for a coworker:
 - First name
 - Last name
 - Number
- 5. Use your keypad to enter the information, then press the **Search** soft key.
- Use the Navigation bar and button to scroll and select the name of the person you would like to call.
- 7. To dial a contact, use one of these options:
 - Press the Dial softkey.
 - Press the Select button.
 - Press the contact label number.
 - Press a line button.
 - Press the Speakerphone button .
 - Press the Headset button .
 - Pick up the handset.

Buttons and Hardware



then press the Transfer button again. Creates a conference call: While already connected to first participant press the Conference button, enter the number, then press the Conference button again. Places active call on hold: Press the Hold button to hold. Press the Hold button again to resume the call. Navigation Bar and Select Button The Navigation bar allows you to scroll through menus and highlight items. The Select button (in the middle of the Navigation bar) allows you to select a highlighted item Headset Button Toggles the headset on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Toggles the microphone on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the headset, headset, and speaker-phone volume (off hook) and the ringer volume (on hook) Mute Button Applications Button Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone			
Additional Phone Lines and Intercom Lines Buttons Buttons illuminate to indicate status: Green, steady—Active call Green, flashing—Held call Amber, steady—Privacy in use, Amber, flashing—Incoming call or reverting call Red, steady—Remote line in use (shared line or Line Status) Red, flashing—Remote line in use (shared line or Line Status) Red, flashing—Remote line on hold Finables softkey options displayed on your phone screen Transfer a call: Press the Transfer button, enter the number, then press the Transfer button again. Creates a conference call: While already connected to first participant press the Conference button again. Places active call on hold: Press the Hold button to hold. Press the Hold button again to resume the call. Navigation Bar and Select Button Red Headset Button The Navigation bar allows you to scroll through menus and highlight items. The Select button (in the middle of the Navigation bar) allows you to select a highlighted item Headset Button Toggles the headset on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Wolume Button Controls the handset, headset, and speaker-phone volume (off hook) and the ringer volume (on hook) Auto-dials your voice messaging system Auto-dials your voice messaging system Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone	1	Handset Light Strip	
Buttons Green, steady—Active call Green, flashing—Held call Amber, steady—Privacy in use, Amber, flashing—Incoming call or reverting call Red, steady—Remote line in use (shared line or Line Status) Red, flashing—Remote line on hold Transfer Button	2	Phone Screen	Shows information about your phone
line or Line Status • Red, flashing—Remote line on hold	3	•	Buttons illuminate to indicate status: Green, steady—Active call Green, flashing—Held call Amber, steady—Privacy in use, Amber, flashing—Incoming call or reverting call
phone screen Transfer Button Press the Transfer button, enter the number, then press the Transfer button again. Conference Button While already connected to first participant press the Conference button, enter the number, then press the Conference button, enter the number, then press the Conference button, enter the number, then press the Conference button again. Places active call on hold: Press the Hold button to hold. Press the Hold button again to resume the call. Navigation Bar and Select Button The Navigation bar allows you to scroll through menus and highlight items. The Select button (in the middle of the Navigation bar) allows you to select a highlighted item Headset Button Toggles the headset on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Volume Button Controls the handset, headset, and speaker-phone volume (off hook) and the ringer volume (on hook) Messages Button Auto-dials your voice messaging system Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone	4	Caffilan Buttan	Red, flashing—Remote line on hold
Press the Transfer button, enter the number, then press the Transfer button again. Conference Button While already connected to first participant press the Conference button, enter the number, then press the Conference button, enter the number, then press the Conference button again. Places active call on hold: Press the Hold button to hold. Press the Hold button again to resume the call. Navigation Bar and Select Button The Navigation bar allows you to scroll through menus and highlight items. The Select button (in the middle of the Navigation bar) allows you to select a highlighted item Headset Button Toggles the headset on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Controls the handset, headset, and speaker-phone volume (off hook) and the ringer volume (on hook) Mute Button Applications Button Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone	4		phone screen
While already connected to first participant press the Conference button, enter the number, then press the Conference button again. Places active call on hold: Press the Hold button to hold. Press the Hold button again to resume the call. Navigation Bar and Select Button The Navigation bar allows you to scroll through menus and highlight items. The Select button (in the middle of the Navigation bar) allows you to select a highlighted item Pheadset Button Toggles the headset on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Toggles the microphone on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone	5	Transfer Button	Press the Transfer button, enter the number,
Press the Hold button to hold. Press the Hold button again to resume the call. 8 Navigation Bar and Select Button 1 The Navigation bar allows you to scroll through menus and highlight items. The Select button (in the middle of the Navigation bar) allows you to select a highlighted item 9 Headset Button 10 Speakerphone Button 11 Keypad Allows you to dial phone numbers, enter letters, and select menu items 12 Mute Button Toggles the microphone on or off 13 Volume Button Controls the handset, headset, and speakerphone volume (off hook) and the ringer volume (on hook) 14 Messages Button Auto-dials your voice messaging system 15 Applications Button Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone	6		While already connected to first participant press the Conference button, enter the number, then press the Conference button
Select Button through menus and highlight items. The Select button (in the middle of the Navigation bar) allows you to select a highlighted item 9 Headset Button Toggles the headset on or off Toggles the speakerphone on or off Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Toggles the microphone on or off Auto-dials your voice messaging system Applications Button Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone	7	Hold Button	Press the Hold button to hold. Press the Hold
10 Speakerphone Button 11 Keypad Allows you to dial phone numbers, enter letters, and select menu items 12 Toggles the microphone on or off 13 Volume Button Controls the handset, headset, and speakerphone volume (off hook) and the ringer volume (on hook) 14 Messages Button Auto-dials your voice messaging system 15 Applications Button Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone	8		through menus and highlight items. The Select button (in the middle of the Navigation bar) allows you to select a high-
Allows you to dial phone numbers, enter letters, and select menu items Toggles the microphone on or off Wolume Button Controls the handset, headset, and speaker-phone volume (off hook) and the ringer volume (on hook) Auto-dials your voice messaging system Applications Button Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone	9		Toggles the headset on or off
letters, and select menu items Toggles the microphone on or off Nute Button Controls the handset, headset, and speaker-phone volume (off hook) and the ringer volume (on hook) Messages Button Auto-dials your voice messaging system Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone	10	Speakerphone Button	Toggles the speakerphone on or off
Mute Button Controls the handset, headset, and speaker-phone volume (off hook) and the ringer volume (on hook) Messages Button Auto-dials your voice messaging system Applications Button Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone	11	Keypad	
phone volume (off hook) and the ringer volume (on hook) 14 Messages Button Auto-dials your voice messaging system 15 Applications Button Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone	12	Mute Button	Toggles the microphone on or off
15 Applications Button Opens/closes the Applications menu. Use it to access call history, user preferences, phone settings, and phone	13	Volume Button	phone volume (off hook) and the ringer
to access call history, user preferences, phone settings, and phone	14		Auto-dials your voice messaging system
	15		to access call history, user
16 Contacts Button Opens/closes the Directories menu	16		Opens/closes the Directories menu
17 Handset Phone handset	17	Handset	Phone handset